



Vacuum tube installation procedure

IMPORTANT NOTICE

This unit is shipped with the vacuum tubes removed and packaged separately. The unit contains lethal voltages. Follow this procedure precisely to prevent electrical shock. Do not touch any electronic components, wire or other internal parts of the unit other than the vacuum tubes.

The tubes you have received should be labeled Vxy, where the x will represent a number, and the y will represent either "L" or "R". This designation indicates the correct location for that tube. The number part is indicated on the silk-screening on the printed circuit board, near the vacuum tube. The letter (L or R) indicates if it is for the left or right channel. If there is no L or R, then it can be used for either channel or is for a power supply.

To install the vacuum tube(s), follow the below procedure:

1. Turn off power to the unit.
2. Wait 15 minutes.
3. Disconnect power cord.
4. Take unit out of rack if necessary.
5. Remove top cover by first removing the 2 Philips screws on the rear panel above the output connectors, then grasping rear lip of the cover panel and pulling up.
6. Select the first tube to install.
7. Install new tube. Make sure it is firmly seated in the socket.
8. Following the same procedure, insert the remaining tube.
9. Replace top cover & reinstall the 2 screws that secure the cover to the chassis.
10. Reinstall unit if required.
11. Insert power cord. Turn on power.
12. Test unit.
13. Procedure complete.